

# CTT Radio Tag User Guide

#### support@celltracktech.com

### 9/22/2021

#### Contents

Introduction Using This Guide	1 2
LifeTag QuickStart Guide	2 3
HybridTag QuickStart Guide	
PowerTag QuickStart Guide	
Final Thoughts	3

#### Introduction

Currently CTT offers digitally-coded radio tags in three distinct flavors:

- 1. **LifeTag** a solar-only tag, this tag is great for diurnally-active species that need the lightest weight available. LifeTags can be as light as 0.35g, and go up from there depending on your species and needs. The most bare-bones tag, plus a flexible tab for harnessing, light nitinol antenna, and enough epoxy coating to protect it from the elements will come in between 0.46 and 0.6g depending on the amount of epoxy. Becuase of their batteryless design, the LifeTag can last for many seasons and years with proper attachment. LifeTag is programmed with a standard 5-second beep rate.
- 2. **PowerTag** PowerTag is the *yang* to the LifeTag's *yin*; a batter-only radio tag with a customizable beep rate, this tag is great for the smallest species, those that are only active at night, or those that are not expected to get sun on their backs during the day.
- 3. **HybridTag** The Hybrid Tag is the best of both worlds, and the go-to tag for most species. Combining the breakthrough technology of the LifeTag with the benefits of a rechargeable battery results in a very light tag (0.65g with light epoxy coating, flexible attachment tab, and light antenna) that can beep 24-hours a day, last multiple seasons and years, and only requires several hours of sunlight over the course of three days to remain fully charged.

#### Using This Guide

Use the Quick Start Guide in the next section to get you up and running with your Digitally-coded Radio Tags. If you run into any complications, please get in touch with us via our Customer Service Desk portal here.

For preparing to deploy any of the three tag types, you will need a way to detect the tag. We recommend either a CTT Locator, or an operational SensorStation and a way to connect to it, either via ethernet or WiFi adapter.

### LifeTag QuickStart Guide

Because there is no battery, deploying a LifeTag is very simple.

- 1. Unpack your LifeTag. Note that your LifeTag ships with an 8-digit digital ID sticker.
- 2. Record the unique digital IDs for each of your tags.
- 3. Place your LifeTag, solar panel facing up, in a location where it can get some direct light and within detection range of your SensorStation (note: if not using antennas on your SensorStation, make sure nodes are within a meter of the station) or CTT Locator.
- 4. If using the locator, power-up and connect your Locator to a smart device following the directions in the Locator User Guide [here] (https://cellular-tracking-technologies.github.io/ctt\_documentation/CTT locator user guide.html).
- 5. Connect your computer to your SensorStation so you can view the web interface (for SensorStation operation consult the online install guide here).
- 6. Ensure your SensorStation has at least one radio tuned to detect Tags (if this isn't clear, consult the SensorStation online install guide).
- 7. You should now see the digital ID of the tag showing up in either the Locator interface on your smart device, or on the radio channels (1 through 5) on the SensorStation Interface on your computer.

## HybridTag QuickStart Guide

Like the LifeTag above, the HybridTag will beep when sun is hitting the panel, but will switch to battery power when there is no light. The HybridTag comes with a small magnet taped to the back of the tag. The magnet keeps the tag from using the battery to transmit its digital signal. By removing the magnet you will activate the battery and, assuming the battery is charged, you should experience immediate beeping.

- 1. Unpack your HybridTag. Note that your HybridTag ships with an 8-digit digital ID sticker.
- 2. Record the unique digital IDs for each of your tags.
- 3. Remove the tape and magnet from the back of your HybridTag and store it for turning off a HybridTag in the future (such as when you're done with this test!)
- 4. If using the locator, power-up and connect your Locator to a smart device following the directions in the Locator User Guide [here] (https://cellular-tracking-technologies.github.io/ctt\_documentation/CTT locator user guide.html).
- 5. Connect your computer to your SensorStation so you can view the web interface (for SensorStation operation consult the online install guide here).
- 6. Ensure your SensorStation has at least one radio tuned to detect Tags (if this isn't clear, consult the SensorStation online install guide).
- 7. You should now see the digital ID of the tag showing up in either the Locator interface on your smart device, or on the radio channels (1 through 5) on the SensorStation Interface on your computer.

8. If the tag fails to beep, and is not in the sun, go ahead and place it in direct sun and see if it then starts to function. If this happens it means that the battery is flat and needs to recharge. Place the magnet back on the tag and place the tag in the sun for several hours to fully recharge. Then repeat the test again, covering the solar panel to ensure that your tag is beeping using battery power.

## PowerTag QuickStart Guide

PowerTags are a little different in that they operate solely on battery, and therefore need a more precice way to activate and deactivate them. The CTT Activator can be used to do both.

- 1. Unpack your PowerTag. Note that your PowerTag ships with an 8-digit digital ID sticker.
- 2. Record the unique digital IDs for each of your tags.
- 3. Follow the directions printed on the CTT Activator to activate your PowerTag.
- 4. Confirm activation on the Activator by seeing the red beep indicator light flashing at the expected beep rate (the beep rate you selected when placing your order).
- 5. If your tag fails to activate at first, try activating in different orientations. The transmitter board is on either side of the tag depending on build, so there are cases when the battery or a thick epoxy may preclude activation from a single orientation; flipping the tag and trying again will usually fix it. All tags are activated and de-activated at the office prior to shipping so there's definitely a correct orientation!
- 6. It is always best practice to confirm tag detection on either a CTT Locator or a CTT SensorStation. See steps 4-7 under HybridTag QuickStart above.

## Final Thoughts

This User Guide is a living document. Your experiences and input are greatly appreciated so please don't hesitate to reach out to us regarding what you'd like to see included here. You can submit your suggestions and any errors to our Customer Service Desk here and we will work to incorporate them in future revisions. All material © Cellular Tracking Technologies, 2021.